

# CORE POLICY AND DEDUCTION

## CRUISE CONTROL

---

### NO CORE CREDIT

- Disassembled units

### TRANSDUCERS

### NO CORE CREDIT

- Housings that are broken, damaged, cracked, frozen or rusted

### 50% LESS CREDIT

- Missing filter cover

## SERVOS

### 50% LESS CREDIT

- Broken/missing plastic vacuum ports
- Cracked/broken plastic housing or diaphragm base
- Broken or missing terminals
- Damaged or missing bracket
- Damaged, cut or missing harness (Ford units)

## MODULES

### NO CORE CREDIT

- Cracked, rusted, corroded, fire damaged, water damaged or missing circuit board

### 50% LESS CREDIT

- Cracked, broken, burnt or damaged case

---

**All cores must be returned in the original box to receive full core credit.**

**All cores not returned in the box receive maximum 10% core credit.**

**Core credit allowed only for units in the current programs.**

**Only exchange cores accepted for core credit.**